FACTORY FURNITURE



Tophat Planters

OPERATION & MAINTENANCE MANUAL



Introduction

Design

Design, shop drawings and development by Factory Furniture Ltd.

Manufacture

Factory Furniture manufactured components. Products are assembled in Factory workshops, checked and dispatched ready for installation. Replacement products or components thereof should be ordered direct from Factory Furniture Ltd.

Copyright

The design copyright for the product and drawing copyright remains the sole property of Factory Furniture I td.

General Specifications

Ø1.2 x 0.5m Planter

Metric length 1200mm | width 1200mm | height 500mm

Imperial length 3' 11" | width 3' 11" | height 1' 71/2"

Approx Weight 141kg **Liner Capacity** 300ltr

Ø2.4 x 0.5m Planter

Metric length 2400mm | width 2400mm | height 500mm

Imperial length 7' 101/2" | width 7' 101/2" | height 1' 71/2"

Approx Weight 335kg **Liner Capacity** 1200ltr

Ø2.4 x 1.0m Planter

Metric length 2400mm | width 2400mm | height 1000mm

Imperial length 7' 101/2" | width 7' 101/2" | height 3' 31/2"

Approx Weight 437kg **Liner Capacity** 2600ltr

N.b. Typically the planters are not fixed to the ground. They are also not designed to be moved once filled with planting material.

Detailed Material & Finish Specifications

Top, Side & Base Assemblies

- Top, side and base assemblies manufactured from lasercut mild steel sheet* (all welded contruction).
- Mild steel assemblies are hot dip galvanised and polyester powder coated (colour grey as standard or to customer specification).
- Assemblies are bolted together using M10 bolts and locknuts to form planter.
- 4 no. Integral lifting eyes are provided to aid transport and positioning on site.

General Maintenance

(Recommended Schedule & Guidelines)

Daily/Weekly/Monthly (or as adopted)

Visual checks of table / stool top, frame and base - check all items for superficial or physical damage

Three Monthly

Clean all items as detailed below check all fixings are seated correctly

Six Monthly

Secure all fixings; full clean as detailed below

Specific Maintenance Details

Polyester Powder Coated & Galvanised

For general cleaning using a damp cloth and warm soapy water only. Scourers and abrasive cleaners are NOT suitable for this type of finish and may damage it. Before using any cleaning agents to remove graffiti etc. try on a small, inconspicuous area first to avoid causing more unsightly damage.

Corten Steel

For general cleaning using a damp cloth and warm soapy water. Before using any cleaning agents to remove graffiti etc. try on a small, inconspicuous area first to avoid causing more unsightly damage.



^{*} Option for Corten steel available

Repairs

Polyester Powder Coated & Galvanised Surfaces

For light damage (scratches, chips etc.) repair using touch-up paint to match original colour (available from Factory Furniture Ltd). Paint application should be carried out in accordance with approved methods detailed by the paint manufacturer. Please note that it is advisable to use professional painters to achieve best results when touching up larger areas. Products for respraying larger areas are available from Factory Furniture Ltd.

Corten Steel

Over a short period of time Corten steel forms a rust patina over exposed surfaces which protects the underlying material from further corrosion. Any light scratches etc. will be covered in this way and so no action is necessary

Heavy Damage

In the event of serious damage to any component, replacements should be ordered from Factory Furniture Ltd. Should further assistance be required (or if the product needs to be disassembled for any reason), please contact Factory Furniture for detailed technical advice.

5 Pioneer Road, Faringdon, Oxfordshire SN7 7BU +44 (0)1367 242731 hello@factoryfurniture.co.uk

