


FACTORY FURNITURE



Pik Picnic Table

OPERATION & MAINTENANCE MANUAL



Introduction

Design

Design, shop drawings and development by
Factory Furniture Ltd.

Manufacture

Factory Furniture manufactured components. Products are assembled in Factory workshops, checked and dispatched ready for installation. Replacement products or components thereof should be ordered direct from Factory Furniture Ltd.

Copyright

The design copyright for the product and drawing copyright remains the sole property of Factory Furniture Ltd.

General Specifications

PIK Picnic Table (Surface fix)

Metric length 3000mm | width 1480mm | height 740mm

Imperial length 9' 10" | width 4' 10½" | height 2' 5"

Approx Weight 318kg

Fixing Centres 1600mm (5' 3") x 750mm (2' 5½")

PIK Picnic Table (Free-standing)

Metric length 3000mm | width 1480mm | height 740mm

Imperial length 9' 10" | width 4' 10½" | height 2' 5"

Approx Weight 340kg

Base Centres 1600mm (5' 3")

Detailed Material & Finish Specifications

Table & Seat Slat

- Manufactured from FSC® softwood (*other FSC options available including tropical hardwood (e.g. Cumaru) or Shou Sugi Ban (charred)*)
- Slats are profiled and left untreated as standard.
- Bolted to frame.



Frame

- Manufactured from mild steel with a hot dip galvanised finish. Polyester powder coated finish available on request (*any RAL colour*)
- Timber slats bolted to spacer and frame and LH and RH sections of frame bolted together.
- Anchored to ground using 8 no. zinc-coated M10 x 75mm sleeve anchors per table (*not freestanding option*)
- Freestanding option available

General Maintenance

(Recommended Schedule & Guidelines)

Daily/Weekly/Monthly (or as adopted)

Visual checks of timber table slats and frame - check all items for superficial or physical damage.

Three Monthly

Clean all items as detailed below check all fixings are seated correctly; inspect timber for serious damage and splinters.

Six Monthly

Secure all fixings; full clean as detailed below; check that table and benches are firmly secured to the ground


Specific Maintenance Details

FSC Timber

Clean with a stiff brush once per year, especially in more exposed locations, in order to prevent a verdigris type build up on the timber surface. Ideally this should be completed in early spring. During the cleaning stage, all exposed timber surfaces should be inspected for splits and splinters. Any splinters and graffiti should be removed and the surface sanded with 100 grit sandpaper in order to remove any uneven / sharp edges or surfaces.

Galvanised & Polyester Powder Coated Surfaces

For general cleaning using a damp cloth and warm soapy water only. Scourers and abrasive cleaners are NOT suitable for this type of finish and may damage it. Before using any cleaning agents to remove graffiti etc. try on a small, inconspicuous area first to avoid causing more unsightly damage.



Repairs

FSC Timber

For light damage, please see section on specific maintenance details above. For instances of heavy damage, the timber item should be replaced. Please order against the part number reference in the reordering section towards the end of this manual.

Galvanised Surfaces


For light damage to hot dipped galvanised finishes repair using a high performance cold galvanising zinc spray (70% zinc or above). Spray application should be carried out in accordance with approved methods detailed by the product manufacturer. Please note that it is advisable to use professional painters to achieve best results when touching up larger areas.

Polyester Powder Coated Surfaces

For light damage (scratches, chips etc.) repair using touch-up paint to match original colour (available from Factory Furniture Ltd). Paint application should be carried out in accordance with approved methods detailed by the paint manufacturer. Please note that it is advisable to use professional painters to achieve best results when touching up larger areas. Products for respraying larger areas are available from Factory Furniture Ltd.


Heavy Damage

In the event of serious damage to any component, replacements should be ordered from Factory Furniture Ltd. In this event (or if the product needs to be disassembled for any reason), please contact Factory Furniture for detailed technical advice.



Assembly Instructions

All installation works to be carried out by competent personnel - install as complete unit.






Step 1

1. Bolt base frame halves together using M12 x 35mm hex bolts and locknuts
2. Hammer on M12 armour ring over bolt heads and lock-nuts


Step 2

1. Bolt 4 off table slats (190 x 68 x 3000mm) onto two off frame assemblies (with slat spacer plates in between) using M10 x 95mm coach bolts and lock-nuts



Step 3

1. Bolt two off seat slats (220 x 68 x 3000mm) onto table assembly as shown using M10 x 90mm coach bolts and lock-nuts
2. Screw on slat tie strap at each end of the table slats using No. 14 x 35mm csk pozi screws (see detail)








Table - Surface fix

Installation Instructions

All installation works to be carried out by competent personnel - install as complete unit.

Pik Picnic Table

1. Install suitable foundation pads (see illustration) each with top face at ground level.
2. Position table in correct orientation with bases centrally on foundation pads; mark hole positions through frame.
3. Remove the table; drill holes $\varnothing 12\text{mm}$ x 75mm deep (or as bolt manufacturer's recommendations).
4. Clear debris from holes.
5. Reposition table and fix to foundation pads using 8 no. zinc-coated M10 x 75mm sleeve anchors tightened to 50Nm (or as per manufacturer's instruction). Ensure table remains level during fixing process







Table - Free-Standing Option



5 Pioneer Road, Faringdon,
Oxfordshire SN7 7BU
+44 (0)1367 242731
hello@factoryfurniture.co.uk

factoryfurniture.co.uk

